
List of figures

Figure 1	
MIRAN interface structure in the Meridian 1 system	5
Figure 2	
MIRAN software architecture	11
Figure 3	
MIRAN software layers	12
Figure 4	
MIRAN and the equipment it replaces	14
Figure 5	
MIRAN block diagram	15
Figure 6	
The NTAG36 MIRAN faceplate	17
Figure 7	
Installing a PCMCIA card into the MIRAN faceplate slot	25
Figure 8	
Administration of multiple MIRAN card using terminal-based OA&M access	26
Figure 9	
Example of a security device	29
Figure 10	
MIRAN multi cross-connect channels relative to the EXUT wiring ..	46
Figure 11	
MIRAN cross-connect channels relative to the XFEM wiring	47

Figure 12	
MIRAN installed in an NT8D37 IPE module	49
Figure 13	
Terminal connection to the MIRAN at the MDF	52
Figure 14	
Analog device connection at the MDF	55
Figure 15	
Terminal-based OA&M connection for multiple MIRAN cards	57
Figure 16	
Multiple MIRAN card connections over the RS-232 port at the MDF	59
Figure 17	
Option 11E or 11C terminal connection	61
Figure 18	
Security device installation location	76
Figure 19	
MIRAN software upgrade	88
Figure 20	
Backup of MIRAN configuration/recordings	90
Figure 21	
Password entry flowchart	100
Figure 22	
Main Menu flowchart	101
Figure 23	
Record menu flowchart, part 1	102
Figure 24	
Record menu flowchart, part 2	103
Figure 25	
Delete menu flowchart	104
Figure 26	
Setup menu flowchart	105